
TRIO® *Ventilateur*


TABLE FAN



USER MANUAL

TTF-1122A
TTF-1162A

Parts Identification



1	Name Plate	8	Rear Guard
2	Front Guard	9	Oscillation Knob
3	Blade Cap	10	Motor Shaft
4	Locking Screw	11	Switch Knob
5	Guard Ring	12	Base
6	Fan Blade	13	Screws
7	Guard Interlocking Nut		

Specifications

Model	**TTF-1122A**	**TTF-1162A**
Rated Voltage	**220-240V~**	**220-240V~**
Rated Wattage	**40W**	**50W**
Blade Size	**12"**	**16"**
Frequency	**50/60Hz**	**50/60Hz**


General Safety Precautions

1. Please read and save these instructions carefully before use.
2. Always switch off and unplug the appliance from the main electrical supply **BEFORE** cleaning and also when the appliance is not in use.
3. Never immerse the appliance in water or other liquids to avoid damage and other hazards.
4. Never leave the appliance unattended while it is connected to the mains.
5. Close adult supervision is necessary when operating appliance, especially where children are present.
6. Ensure the electrical cord does not hang over the work surface.
7. Do not operate the appliance with a damaged cord set, or plug. Any repairs should always be carried out by the Customer Service Centre or by an authorized service centre.
8. Do not place the appliance on or near a hot gas or electric burner, in a heated oven, or near easily flammable materials.
9. Always place appliance on a flat sturdy surface. When moving appliance, always take precaution not to touch hot surfaces.
10. Use of accessories or equipment not supplied by the manufacturer may cause damage or result in the malfunctioning of your appliance or bodily injuries.
11. This appliance is intended for household use only.
12. This appliance should not be used by the physically challenged, slow response or mentally disabled people (including children) unless guidance is provided during operation.

How to Assemble Your Fan

1. Attach the rear guard to the front side of the motor; fasten the guard interlocking nut by turning it clockwise until the guard is secured firmly in place.
2. Mount the fan blade onto the motor shaft; fasten the blade cap by turning anti-clockwise firmly.
3. Installing the front guard:
   a. Open the front guard clip and attach the hook to the rear guard.
   b. Push the round edges of front guard to fit it securely into the rear guard.
   c. Close the clip and tighten the locking screw.

4. Installing the base:
   a. Insert the stand body to the base unit.
   b. Lead the power cord through the recess at the back of the base. Insert the rear side of the stand body firmly until a ‘click’ sound is heard.



Note: Ensure the stand body is COMPLETELY interlocked with the base unit.

How to Use Your Fan


1. Connect the plug into a power supply socket and switch on the power.

2. Switch ON the fan by pressing the control knob at any of the “3”, “2” or “1” settings.


3. Press the “3”, “2” or “1” knob to adjust the fan speed from High-Medium-Low.

4. To stop the fans, press the “O” knob.

5. To tilt the fan, always ensure that the fan is in ‘OFF’ position and wait until the blade has completely stopped for safety reasons. Hold the stand firmly with one hand and move the guard gently upwards or downwards.



6. The oscillation knob is positioned at the top of the rear motor housing. Press the knob down to make the fan oscillate and pull it up to stop oscillation.



Care and Cleaning

1. Always ensure that the power supply is OFF and the power cord unplugged from the power supply. Wait until the blade has completely stopped before cleaning.

2. Wipe the surfaces of the fan, the base and the fan blade with a soft damp cloth. Never use any corrosive cleaning solution.
3. For proper storage, always place the fan in a low humidity environment.



This marking indicates that this product should not be disposed with other household wastes throughout the nation. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

TRIO®

Ventilateur

